



Single Section Scorer's Table

Rev	--
-----	----


Step 1: Screw brackets to possession indicator with Nevco provided screws.




SPI-BB




Step 2: Screw brackets to scorer table with Nevco provided screws. The screws will screw into threaded inserts in the scorer table.



Plug possession indicator's wall wart into power strip in scorer table.




Installation Possession Indicator		 Nevco, Inc. Greenville, Illinois 62246	
		Drawing No. 241-0387	
Drawn WHP	Date 2/8/2021	Sheet 1	of 2


Multi-Section Scorer's Table

Rev --

Step 1: Screw brackets to possession indicator with Nevco provided screws.




SPI-BB



Step 2: Screw brackets to scorer table with Nevco provided screws. The screws will screw into threaded inserts in the scorer table.


Multi-section tables have possession indicators installed towards center of tables

Plug possession indicator's wall wart into power strip in scorer table.



DETAIL B

Right table section not shown



Installation Possession Indicator



Nevco, Inc.
Greenville, Illinois 62246

Drawing No. 241-0387

Drawn WHP

Date 2/8/2021

Sheet 1 of 2